Z_13001 Subject to change. Belimo Aircontrols (USA), Inc.

Gas Monitors









Scan the QR code to view the Operating Manual: See section **3 for installation**, section 4 for operation, and section 6 for maintenance.





Important. All wiring must conform to local building codes, regulations and laws. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



- 1) General:
 - a) Do not obstruct the gas monitor.
 - b) Do not ground the AC/DC 24 V power supply.
- - a) Use 18...20 AWG (2.5...0.5 mm²) single pair cable for power b) Maintain the same polarity (AC/DC 24 V) for all devices.
- 2) Communication (CAN bus, BACnet MS/TP):
 - a) Use 22...24 AWG (0.34...0.25 mm²) twisted pair, shielded jacketed, low capacitance cable for communication
 - b) Maintain the same polarity for all devices.
 - c) All devices must be connected in series
 - d) Switch end of line (EOL) jumpers to "On" on first and list devices on the network.

