



Figure 31 –Parts

MODEL	#1 – T&P RELIEF VALVE	#2 – CONTROL WELL
SSU-20	TP1500 (Not Included)	PMW-3SENP-1
SSU-30	TP1500 (Not Included)	PMW-3SENP-1
SSU-30LB	TP1500 (Not Included)	PMW-3SENP-1
SSU-45	TP1500 (Not Included)	PMW-3SENP-1
SSU-60	TP1500 (Not Included)	PMW-3SENP-1
SSU-80	TP1400 (Included)	PMW-3SENP-1
SSU-119	TP1400 (Included)	PMW-3SENP-1
SSU-45C	TP1400 (Included)	PMW-3SENP-1
SSU-60C	TP1400 (Included)	PMW-3SENP-1
SSU-80C	TP1400 (Included)	PMW-3SENP-1
SSU-119C	TP1400 (Included)	PMW-3SENP-1
SSU-45DW	TP1500 (Not Included)	PMW-3SENP-1
SSU-60DW	TP1500 (Not Included)	PMW-3SENP-1
SSU-80DW	TP1500 (Not Included)	PMW-3SENP-1
SSU-119DW	TP1500 (Not Included)	PMW-3SENP-1

Table 8 – Replacement Parts