

HD Series

Premier Horizontal Evaporator Coils

with Side Connections



Contents	Page
Nomenclature.....	2
Dimensions	3
Airflow Data.....	4



Product improvement is a continuous process at Advanced Distributor Products. Therefore, product specifications are subject to change without notice and without obligation on our part. Please contact your ADP representative or distributor to verify details.
© by **Advanced Distributor Products**. All rights reserved.

Product Features

- Rifled copper tubing.
- Short cabinet with easy access.
- Lanced fin design.
- Dual 3/4" FPT condensate drains on front and back of coil allows flexibility of placement to accommodate left or right airflow furnaces.
- Refrigerant connections are 3/8" ODF liquid and 7/8" ODF suction.
- Non-captive panels allow access to inside of cabinet without the need to cut refrigerant lines.
- Side panel with only six screws for fast and easy coil access.
- UV resistant drain pans are molded of high temperature (450 deg. F) engineered polymer.
- Coils are air pressure tested at 500 psi, leak tested with Helium, sealed with rubber plugs and then charged with dry air.
- Threaded expansion valves available factory installed or as a field installed kit.
- Heavy 24 gauge embossed galvanized cabinets fully lined with 5/8" foil faced insulation.
- All coils are foam packed and include bar coding on label.
- Easy to use filler strip, if coil dimensions are larger than furnace.
- Drain pan has trough to fully drain condensate away.
- Microban[®] antimicrobial additive to inhibit the growth of mold and mildew in the drain pan.

Nomenclature

	H	D02	2	24	E	145	B	21	47	59																										
Cabinet Color H = Embossed A = Armstrong																																				
Slab Number																																				
Metering Device ^[1] 1 = Piston (R-410A) 2 = Piston (R-22) 3 = Bleed A/C TXV (R-22 only) 4 = Non-bleed A/C TXV (R-22) 5 = Non-bleed HP TXV (R-22) 6 = Non-bleed A/C TXV (R-410A) 7 = Bleed HP-A/C TXV (R-410A) 8 = Bleed A/C TXV (R-410A) 9 = Non-bleed HP TXV (R-410A) <i>[1] 7 and 8 valve options available only for York family products.</i>																																				
Nominal MBTUH																																				
Cabinet Width E = 21.5" (standard)																																				
Cabinet Height 145 = 14.5" 175 = 17.5" 210 = 21.0" 245 = 24.5"																																				
												Florator Piston Size ^[2] AP = TXV access port ^[3] <table border="1"> <thead> <tr> <th>MBTUH</th> <th>R-22</th> <th>R-410A</th> </tr> </thead> <tbody> <tr><td>18 =</td><td>53</td><td>49</td></tr> <tr><td>24 =</td><td>59</td><td>53</td></tr> <tr><td>30 =</td><td>67</td><td>59</td></tr> <tr><td>36 =</td><td>73</td><td>67</td></tr> <tr><td>42 =</td><td>80</td><td>73</td></tr> <tr><td>48 =</td><td>84</td><td>76</td></tr> <tr><td>60 =</td><td>93</td><td>93</td></tr> </tbody> </table> <p><i>[2] Piston will always be sized to match the nominal MBTUH rating of the coil.</i> <i>[3] Standard on factory installed TXVs. Optional for piston models.</i></p>	MBTUH	R-22	R-410A	18 =	53	49	24 =	59	53	30 =	67	59	36 =	73	67	42 =	80	73	48 =	84	76	60 =	93	93
MBTUH	R-22	R-410A																																		
18 =	53	49																																		
24 =	59	53																																		
30 =	67	59																																		
36 =	73	67																																		
42 =	80	73																																		
48 =	84	76																																		
60 =	93	93																																		
												Product Code 47 = Refrigerant connections on side of cabinet																								
												Cabinet Length 21 = 21.5" <i>Note: Cabinet length not a selectable option, see cased dimensions.</i> 26 = 26.5" 31 = 31.5"																								
												Duct Flange B = 0.75" (standard)																								



Dimensions

Slab Number	Nominal Tonnage	Pallet Quantity by Cabinet Height				Length (in)	Weight (lbs)
		14.5"	17.5"	21.0"	24.5"		
D02	1.5 - 2.5	16	16	-	-	21.5	47
D03	2.0 - 3.0	8	8	6	-	26.5	49
D04	2.5 - 3.5	-	8	6	2	26.5	45
D05	2.5 - 4.0	-	8	6	-	26.5	47
D06	3.0 - 4.0	-	8	6	2	26.5	50
D07	3.0 - 5.0	-	-	6	2	26.5	57
D08	3.5 - 5.0	-	-	6	2	26.5	80
D09	3.5 - 5.0	-	-	-	2	26.5	87
D11	1.5 - 2.5	16	16	-	-	21.5	50
D12	2.0 - 3.0	8	8	-	-	26.5	50
D13	2.5 - 3.5	-	8	6	2	26.5	50
D14	2.5 - 4.0	-	8	6	-	26.5	50
D15	3.0 - 4.0	-	8	6	-	26.5	56
D16	3.0 - 5.0	-	-	6	2	26.5	64
D17	3.5 - 5.0	-	-	6	2	26.5	56
D18	3.0 - 5.0	-	-	-	2	26.5	58
D19	3.5 - 5.0	-	-	6	2	26.5	60
D20	3.5 - 5.0	-	-	-	2	26.5	60
D47	2.0 - 3.0	-	-	6	2	26.5	60
D48	2.0 - 3.0	-	-	-	2	26.5	60
D50	3.5 - 5.0	-	-	4	2	31.5	63
D51	3.5 - 5.0	-	-	-	2	31.5	63
D52	3.5 - 5.0	-	-	4	2	31.5	63
D53	3.5 - 5.0	-	-	-	2	31.5	63

Opening Type	Opening Dimensions by Cabinet Height			
	14.5"	17.5"	21"	24.5"
Supply opening (Height x Width)	13" x 19.75"	16" x 19.75"	19.5" x 19.75"	23" x 19.75"
Return opening (Height x Width)	13.5" x 20.25"	16.5" x 20.25"	20" x 20.25"	23.5" x 20.25"

Refrigerant Connections
Liquid Line - 3/8" ODF
Suction Line - 7/8" ODF

Drain Connections
3/4" FPT



Airflow Data

Slab Number	Nominal Tonnage	^ Air Pressure Drop (in WC) by CFM							
		600	800	1000	1200	1400	1600	1800	2000
D02	1.5 - 2.5	0.17	0.27	0.40	-	-	-	-	-
D03	2 - 3	-	0.16	0.24	0.32	-	-	-	-
D04	2.5 - 3.5	-	-	0.20	0.27	0.34	-	-	-
D05	2.5 - 4	-	-	0.16	0.22	0.28	0.35	-	-
D06	3 - 4	-	-	-	0.17	0.22	0.27	-	-
D07	3 - 5	-	-	-	0.15	0.19	0.24	0.30	0.35
D08	3 - 5	-	-	-	0.12	0.15	0.19	0.23	0.27
D09	3.5 - 5	-	-	-	-	0.13	0.16	0.19	0.23
D11	1.5 - 2.5	0.19	0.30	0.44	-	-	-	-	-
D12	2 - 3	-	0.19	0.27	0.37	-	-	-	-
D13	2.5 - 3.5	-	-	0.22	0.29	0.38	-	-	-
D14	2.5 - 4	-	-	0.18	0.24	0.31	0.39	-	-
D15	3 - 4	-	-	-	0.19	0.24	0.30	-	-
D16	3 - 5	-	-	-	0.17	0.22	0.27	0.33	0.39
D17	3 - 5	-	-	-	0.13	0.17	0.21	0.25	0.30
D18	3 - 5	-	-	-	0.11	0.14	0.18	0.22	0.26
D19	3.5 - 5	-	-	-	-	0.22	0.28	0.34	0.40
D20	3.5 - 5	-	-	-	-	0.19	0.24	0.29	0.34
D47	2 - 3	-	0.11	0.16	0.23	-	-	-	-
D48	2 - 3	-	0.09	0.14	0.19	-	-	-	-
D50	3.5 - 5	-	-	-	-	0.15	0.19	0.24	0.29
D51	3.5 - 5	-	-	-	-	0.13	0.16	0.20	0.24
D52	3.5 - 5	-	-	-	-	0.20	0.26	0.32	0.39
D53	3.5 - 5	-	-	-	-	0.17	0.22	0.27	0.33

^ Air pressure drop data is under dry coil conditions. For wet coil conversion at standard AHRI conditions, use 1.3 multiplier.

